





Packing list (See Picture 1)


1、Control box	1PC
2、Buzzer/Voice module LED/ LCD Display screen	1PC
3、Ultrasonic sensor	4, 6 or 8 PCS
4、Power cable	1PC
5、Drill bit	1PC
6、Instruction manual	1PC




Picture 1



Picture 1



Picture 1



Picture 1

Catalogue

User's Guide

1. Introduction.....	1
2. Product character.....	1
3. Using method.....	3
4. Using notice.....	7

Installation Guide

1. Installation notice.....	8
2. Ultrasonic sensor installation.....	9
3. Power cable connection.....	12
4. Control box connection.....	13
5. Sensor sensitivity adjustment.....	15
6. Setting detection distance of front sensor.....	15
7. Fix control box.....	16
8. Fix Buzzer/Voice Module, LED / LCD screen.....	16
9. Technical parameter.....	17
10. Problem and solution.....	18

User's Guide

Introduction

Parking sensor system is supplementary safety equipment that is specially designed for car reversing. There is hidden trouble while reversing because of blind zone behind the car. After installing parking sensor, when reversing.


- *Buzzer/Voice Module detects obstacle behind the car and sends out four beeping tone or voice warning as a reminder.
- *LED system displays the distance on the screen and sends out four beeping tone as a reminder.
- *LCD system displays the distance of obstacles on the screen with voice alert, or can be matched with four beeping tone as a reminder.

So that it is more relax and safe while reversing.

Product character

- Non-ground detecting technology: the ultrasonic beam is flat shape(see Picture 2)
- The obstacle lower than 1cm can not be detected so that system works very stably.
- Intellectualized anti-interference analysis system, lower error report
- Sensor sensitivity can be chosen by the user.
- Superbright & colorful display screen.

- For LED series, can be matched with optional voice module, easy installation, reports distance with graceful sounds.
- All plugs are sealed in the control box, dustproof, moistureproof and never loose.



Picture 2

Using method

Front Sensor

- *Front sensors start to work upon braking activation. If there is not any obstacle within 0.6 meter or 0.9 meter in the front of car (the distance can be set), system displays nothing.
- *Otherwise, system displays the distance of obstacle and reports the distance rapidly with graceful sounds. (Only for 6 or 8 sensors.)
- *If the red wire connect to ACC, front sensors stop work after release the braking for 5 seconds.
- *If the red wire connect to brake, front sensors stop work as soon as release the braking.
- *Front sensors do not work when the vehicle is in reverse. (Only for 6 or 8 sensors)
- *Front sensor's detection range: 0.3 to 0.6m(default) and 0.3 to 0.9m(optional).

Rear Sensor

Rear sensors are activated when reverse gear is engaged. System automatically switches to reversing distance indication. If there is no obstacle within 2 meters behind the car, it displays " " . When the obstacle moves closer.

- *Voice system reports the distance with graceful sounds, the volume can be chosen for high, middle, low by the user.
- *Buzzer system sends out four beeping tone as a reminder, please see table 1.
- *LED system displays the distance of obstacle on the screen and sends out four beeping tone as a reminder.
- *If it is assembled with the voice module, when reversing, it reports the distance with graceful sounds.
- *LCD system displays the distance of obstacles on the screen with voice alert, or can be matched with four beeping tone as a reminder.

Please see table 1:


Table 1: Safety distance and buzz

Distance (meter)	Distance (feet)	Buzz
>1.0	>3.0	No Buzz
1.0-1.0	3.0-3.3	Slow Buzz
1.0-0.7	3.3-3.0	Medium speed Buzz
0.7-0.3	2.3-1.0	Quick Buzz
<0.3	<1.0	Urgent Buzz


Due to the inertia of the car, it will show the distance 10cm (1 inch) less than the real distance.

Display information, please see Picture 3


Left direction Obstacle distance Right direction



Picture 3




216LED-F Dash Mount Display Information




216LED-F Up-mount(inversion) Display Information

Picture 3




226LED-F LED Parking Sensor




217LED-F LED Parking Sensor

Picture 3



217LCD-F Display Information



218LCD-F Display Information


Picture 3

Front sensor's turn on and turn off (only for MP-2200 (1B-V))

When stepping on the brake gear, press the switch (see picture3), it can turn on or off front sensor distance display function. If the front sensor display function is closed and the speaker is mute, front sensor is still in working, the 3 mark () on the left top of screen will be lighted as Green/Yellow/Red to be a reminder. When the front sensor distance display function is turned on, the system displays the obstacle distance on screen and send out voice warning at same time.

Volume Control:

Press the switch for 1 second, the LCD screen display 0/1/2, correspond to mute/under tone/loudness.




Switch for front sensor display turn on or off and volume control 220LED-F display information


Picture 3

228LCD:
Different background (green, orange or red) based on different obstacle distance.

Volume could be adjusted by slide switch in the back, could choose music/under tone/ loudness.



228LCD-F/V LCD Parking Sensor



219LCD-F/V LCD Parking Sensor

Picture 3


Using notice

- Parking sensor is designed only for reverse assistance. The driving safety depends on the driver's prudence. Our company will not be responsible for the traffic accidents.
- As the system does not connect to car brake system, please brake immediately once hearing rapidly "di-di" reminder.
- Do not press the sensor case. Please clean the ice, snow, silt or others dust away of the surface of sensors.
- All parking sensors may fail to detect the following objects based on the ultrasonic detecting principle:
 - 1) Vertical objects lower than the sensor such as pillar and low wall
 - 2) Sharp corners, such as corner of wall, diagonal quadrate pillar
 - 3) Blurred objects, such as trunk, horizontal sight pole and projecting steel bar
 - 4) Objects or shapes which are disadvantage for ultrasonic wave projection, such as the wheels of bike, human body is away from one meter or a box.

Installation Guide

Installation notice


- 1) Please ensure the power is OFF prior to connecting any wires.
- 2) All joints should be enclosed more than 5 circles with good insulation.
- 3) Do not press the sensor core during installation.
- 4) Front sensor installation with the order of E,F,G,H
- 5) Rear sensor installation with the order of A,B,C,D
- 6) Sensor cable is connected to the control box with the order of E,F,G,H,A,B,C,D
- 7) Please do not close up the original or face to the cooling fan during front sensor installation.
- 8) Do not have anything higher than sensors on the body.
- 9) The sensor and control box have been matched strictly in production. Different types of sensor can not be exchanged.
- 10) Other notice please see Picture 4




Picture 4

Ultrasonic sensor installation


Front Sensor is installed on the shell beside of the headlight, rear sensor is installed on the back bumper. Choosing a place where is vertical with the ground or a bit up tilting to the ground, please see Picture 5. It should be installed 5°-10° degree up tilting to the ground if the installation position is lower than 50 cm to the ground.



Picture 5 Sensor plumbs the ground or slightly filled




Picture 6 Rear Sensor installation distance



Picture 7 Front Sensor installation distance

Drill the hole by which prepared in the package, please see Picture 8. After drilling, please clean the edge of hole.



Put the sensors into the holes according to Picture 5, sensor cables go through into the trunk of car.

Power cable connection

4 sensors: Please see Picture 9

- Red wire connect to the anode of reversing light.
- Black wire connect to the cathode of reversing light or ground.

Picture 9 Power cable connection(4 sensors)

6 or 8 sensors: Please see Picture 10 & 11

- Red wire connect to the anode of brake.
- Yellow wire connect to the anode of reversing light.
- Green wire connect to the anode of brake.
- Black wire connect to the cathode of reversing light or ground.

Picture 10 Power cable connection for automatic transmission(6 or 8 sensors)




Picture 11 Power cable connection for manual transmission(6 or 8 sensors)


Control box connection

Before connection, pls remove the screws of the control box firstly. 4 sensors Please see Picture 12.

- Insert the sensor cable into the four sockets A, B, C, D from left to right.
- Insert the power cable into F socket.
- Insert the display screen cable into G socket.
- Insert the voice module cable into H socket if selection.
- Arrange the cable in a good order and then screw the lid tightly.



Picture 12



8 SENSORS

Picture 13

- 6 or 8 sensors: Please see Picture 13
- Insert the front sensor cables into the four sockets (I, J, G, and H) from left to right.
 - Insert the rear sensor cables into the four sockets A, B, C, and D) from left to right.
 - Insert the power cable into J socket.
 - Insert the display screen cable into K socket.
 - Insert the voice module cable into L socket if selection.
 - Arrange the cables in a good order and then screw the lid tightly.

Sensor sensitivity adjustment

The system is already set to a middle sensitivity when ex work. If the error report appears frequently in using please move the sensitivity pin to high or low.

Setting detection distance of front sensor


Please choose the detection range as per Picture 14 indication:
 0.6M means the farthest range is 0.6M.
 0.9M means the farthest range is 0.9M.
 Off means the front sensor is closed.

Fix control box

Tear off the shield of the velcro strap on the back of control box and stick on the sidewall of the trunk. If the sidewall of trunk is covered by felt, please take off the half of the velcro and stick on the felt directly. Clean the dust before sticking.

Fix Display Screen

Tear off the shield of the velcro strap under the screen and stick on the left corner of the dashboard. Clean the dust before sticking.



Picture 14 Setting detection distance of front sensor

Technical Parameter

Working voltage: DC 10-16 V
 Working current: ≤200mA for Buzzer
 Working current: ≤20mA for Voice
 Power protection for wrong connection: yes
 Fuse: built-in automatic recovery fuse
 Rear detection distance: for Buzzer: 0.3m-1.5m (1-4.92ft)
 Rear detection distance: 0.30m-2m (1-6.56ft)
 Rear sensor cable length: 2.50m
 Front detection distance: 0.30m-0.60m(default) Or 0.30m-0.90m(optional), also can be closed
 Front sensor cable length: 7.60m
 Display screen cable length: 5.70m or 6.60m(with extra connector)
 4 sensors control box: 105*75*21mm
 6/8 sensors control box: 140*90*25mm
 214 141-F Screen Size: 141*93mm
 2141 F1-F Screen Size: 90*28*20mm
 217 2181 CD-6V Screen Size: 81*49*8mm
 220L CD-FV Screen Size: 80*55*13mm
 Working temperature: -40°C ~ +80°C (LCD)
 -20°C ~ +75°C (LCD)

Problem and solution

Table 2 Problem and solution

Number	Problem	Solution
1	No display when reverse park is engaged	1. Check if power cable is connected properly 2. Check if power cables are connected to the correct socket 3. Check if display screen cables are connected to the correct socket
2	Front sensors don't work	1. Check if front light is a good condition 2. Check if the shield cables are connected to the correct socket 3. Check if the shield cables are connected to the correct socket 4. Check if the shield cables are connected to the correct socket
3	Display not working	1. The plug is connected with other holes, the connector is loose 2. Check if the power cable connects to the correct socket
4	Wrong display	1. Check if the pressure, air, wiring, battery or bracket is wrong 2. Check if the display is in a good condition 3. Check if the sensor cables are connected to the correct socket 4. Check if the sensor cables are connected to the correct socket 5. Check if the plug is connected to the correct socket 6. Check if the plug is connected to the correct socket

6	Keep sensor off road control	Turn it on
6	Low sensitivity	1. Clean the sensor for the surface of sensor 2. Check that plug and pins are connected firmly 3. Clean the sensor cable
7	No alarm high display	1. No obstacle 2. Check sensor
8	Block light	Prevent the sensor cable or ground
9	Sensor not good and connected	Check if the plug and pins are connected firmly
10	Display when driving	Check if the plug is connected firmly
11	Display when not driving	Check if the plug is connected firmly

